Model: Treo 180 & 270

1 - Switch ON your phone without SIM Card,

2 - Compose: *#*#CODE#

Model: Treo 600

- 1 Switch ON your phone with Allowed SIM Card,
- 2 Go to Menu and select "Phone Tool" or "Phone Application"
- 3 Type on Virtual Keyboard *#*#CODE#
- 4 Select with PEN "Numer" and phone will show that's unlocked now!

or

- 1 Switch ON your phone with a not Allowed SIM Card,
- 2 Enter the Unlock Code we send to you.

Model: Palm Pre and Palm Pre Plus

- 1. Turn off cell phone put in a not allowed SIM card.
- 2. Turn on cell phone phone asks for network unlock pin (referring to the unlock code).
- 3. Enter pin number once (at this point there is no error)
- 4. Phone states SOS only calls when you try to make a regular call it will ask for the network unlock pin again. At this point no matter how many times you put in the pin. It will state incorrect pin message.
- 5. Reboot phone with the same not allowed SIM card.
- 6. After reboot, it's unlocked and never asked for the network unlock pin again.