□



□ Vũ ng□c - mobile nh□n s□a l□i đi□n tho□i di đ□ng, Modem b□ m□t Boot(BRICK) trong quá trình nâng c□p ph□n m□m, s□a l□i Software,Unlock, S□a l□i b□ m□t 3G "WCDMA", S□a l□i b□ m□t 2G "GSM", Repair 3G, Repair 2G, S□a l□i m□t IMEI, S□a l□i m□t Baseband, Gi□i mã, M□ m□ng, B□ khóa, Up rom... b□ l□i (Máy b□ m□t ngu□n, không vào đ□□c ch□ đ□ Download mode, S/W upgrade ...ho□c treo...) Repair Boot, Unbrick Samsung, Sony Xperia, LG, Nokia lumia, Microsoft Lumia, CYON, Anycall, Docomo, Softbank, SHOW, Pantech SKY, HTC, Kt tech, TAKE...

Danh sách CPU h□ tr□ Repair boot - Unbrick (Không c□n tháo máy):

- **- APQ8060, APQ8060A, APQ8064, APQ8084**
- **- MSM7225, MSM7227, MSM7227A**

- **- MSM8210, MSM8225, MSM8226, MSM8260, MSM8260A**
- **- MSM8610, MSM8660, MSM8660A**
- **- MSM8926, MSM8930, MSM8960**

- **- MSM8974, MSM8974AC**

- **- MSM8996**
- **- OMAP3660, OMAP4430**

- **- S5PC110**
- **- AP20H NIVIDA Tegra 2**
- **- NIVIDA Tegra 2 250 T20**

Danh sách model h□ tr□ Repair boot, unbrick online - offline (Không c□n tháo m□ máy hàn dây):

Samsung : (No need Open phone for repair boot,unbrick)

- **- SHV-E110S Galaxy SII LTE - Supported -**
- **- SHV-E120L, SHV-E120K, SHV-E120S Galaxy SII HD LTE - Supported -**
- **- SHV-E150S Galaxy Tab 7.7 LTE M16**
- **- SHV-E160L, SHV-E160K, SHV-E160S Galaxy Note (16G) - Supported - Xem thông tin**
- **-**
- **- nttDocomo SC-03D Galaxy SII LTE - Supported -**

- **- nttDocomo SC-04D Galaxy Nexus**
- **- nttDocomo SC-05D Galaxy Note LTE - Supported -**
- **- nttDocomo SC-01E Galaxy Tab 7.7 Plus (SGH-N015) -**
- **- nttDocomo SC-01F Galaxy Note 3 (SM-N900D - SGH-N075) - Supported**
- **- nttDocomo SC-02F Galaxy J**
- **- au KDDI SCL22 Galaxy note 3 (SM-N900J) - Supported**

-
- **- SGH-i337 Galaxy S4**
- **- SGH-i577 Galaxy Exhilarate**
- **- SGH-i717 Galaxy Note LTE**
- **- SGH-i717D Galaxy Note**
- **- SGH-i727 Galaxy SII Skyrocket - Supported -**

- **- SGH-i727R Galaxy SII LTE (Samsung celox)**
- **- SGH-i747 Galaxy SIII - Supported**
- **- SGH-i757M Galaxy SII HD LTE (Samsung Dali)**
- **- SGH-T879 Galaxy Note**
- **- SGH-T989 Galaxy SII Plus (Samsung Hercules)**
- **- GT-i9100G Galaxy SII - Supported -**
- **- GT-i9103**
- **- GT-i9210, GT-i9210T Galaxy SII LTE EU - Supported -**
- **- GT-i9250 - Galaxy Nexus - Supported -**

- **- GT-I9500, GT-i9500Z Galaxy S4**
- **- GT-i9505 Galaxy S4 LTE**
- **- GT-N7005 Galaxy Note LTE**
- **- GT-N8000 Galaxy Note II 10.1**

- **- GT-P1000 Galaxy Tab 7.0**
- **- GT-P3100 Galaxy Tab 2 7.0**
- **- GT-P7300 Galaxy Tab 8.9**
- **- GT-P7310 Galaxy Tab 8.9 Wi-Fi**

- **- GT-P7500 Galaxy Tab 10.1**

- **- GT-P7510 Galaxy Tab 10.1 WiFi-**
- **- SM-A300F, SM-A300H**
- **- SM-A500F, SM-A500H, SM-A500M**
- **- SM-N9005 Galaxy Note 3 - Supported -**
- **- SM-N900W8 Galaxy Note 3 -**

- **- SM-N900S, SM-N900L, SM-N900K Galaxy Note 3**

- **- SM-N910F, SM-N910H, SM-N910C, SM-N910P, SM-N910G, SM-N910T, SM-N910A**
- **- SM-G900F, SM-G900H Galaxy S5 - Supported**
- **- SM-R350 Galaxy Gear Fit - Supported**
- **- SM-R380 Galaxy Gear 2 - Supported**
- **- SM-R381 Galaxy Gear - Supported**

-

LG : (Repair boot,Unbrick - Không c□n tháo m□ máy hàn dây)

- **LG-LU6200 Optimus LTE - Supported -**
- **LG-SU640 Optimus LTE**
- **LG-P720, LG-P725 Optimus 3D Max - Supported -**
- **LG-P760, LG-P765, LG-P768, LG-P769, LG-P778 Optimus L9 - Supported**
- **LG-P920 Optimus 3D - Supported -**
- **LG-P925 Thrill 4G**
- **LG-P930 Nitro HD - Supported -**
- **LG-P935 Optimus 4G LTE**
- **LG-P936 Optimus True HD LTE**
- **LG-P940, LG-P940H Prada 3.0 - Supported -**
- **LG-F120L, LG-F120K, LG-F120S Optimus LTE Tag**
- **LG-F160L, LG-F160K, LG-F160S Optimus LTE2 - Supported**
- **LG-F180L, LG-F180K, LG-F180S Optimus G - Supported**
- **LG-F200L, LG-F200K, LG-F200S Optimus VU II**
- **LG-F220K Optimus GK**
- **LG-F240L, LG-F240K, LG-F240S Optimus G Pro**
- **LG-F260S Optimus LTE3**
- **LG-F300L, LG-F300K, LG-F300S Optimus VU3**
- **LG-F310L, LG-F310LR LG GX**
- **LG-F320L, LG-F320K, LG-F320S Optimus G2 - Supported**

- **LG-F340L, LG-F340K, LG-F340S Flex - Supported**
- **LG-F350L, LG-F350K, LG-F350S G Pro2 - Supported**
- **LG-F400L, LG-F400K, LG-F400S LG G3**
- **LG-F460L, LG-F460K, LG-F460S LG G3 LTE-A**
- **LG-SU540 Prada 3.0 - Supported -**
- **LG-KU5400 Prada 3.0 Supportrd -**
- **LG-SU760 Optimus 3D - Supported -**
- **LG-SU870 Optimus 3D Cube - Supported - Xem thông tin**
- **L-02D Prada - Supported - Xem thông tin**
- **L-01D Optimus LTE**
- **LG-L22 G2 - Supported**
- **LG-D800, LG-D802, LG-D803, LG-D805, LG-D806 Optimus G2 - Supported**

Pantech SKY : (No need Open phone for repair boot,unbrick)

- **- SKY IM-A760S (SKY EF33S) Vega Racer - Supported -**
- **- SKY IM-A770K (SKY EF34K) Vega Racer - Supported -**
- **- SKY IM-A775C Vega Racer - Supported**
- **- SKY IM-A800S (SKY EF39S) Vega LTE - Supported -**

- **- SKY IM-A810K (SKY EF40K) Vega LTE M - Supported -**
- **- SKY IM-A810S (SKY EF40S) Vega LTE M - Supported -**
- **- SKY IM-A820L (SKY EF65L) Vega Ex - Supported -**
- **- SKY IM-A830L, IM-A830K, IM-A830S Vega Racer 2□ - Supported -**
- **- SKY IM-A850K (SKY EF49K) Vega R3 - Supported -**
- **- SKY IM-A850L (SKY EF50L) Vega R3 - Supported -**
- **- SKY IM-A850S (SKY EF48S) Vega R3 - Supported -**
- **- SKY IM-A860L, Im-A860K, IM-A860S Vega No6**
- **- SKY IM-A870K, IM-A870L, IM-A870S Vega IRON**
- **- SKY IM-A880S Vega LTE-A**
- **- SKY IM-A890L, IM-A890S, IM-A890K Vega Note Secret**
- **- SKY IM-A900L, IM-A900S, IM-A900K Vega Secret UP**
- **- SKY IM-A910L, IM-A910S, IM-A910K Vega IRON 2**
- **- SKY IM-T100K Vega N05 - Supported**

HTC & Other : (No need Open phone for repair boot,unbrick)

- **Kttech KM-S200 Take**
- **KTtech KM-S220 Take Tachy**
- **KTtech KM-S300 Take HD**
- **Kttech KM-S330 Take Fit**
- **Nokia Lumia V1 : 520, 521, 525, 620, 625, 720, 820, 920, 928, 1020, 1320**
- **Nokia Lumia V2 : 530, 630, 635, 638, 930, 1520**
- **Microsoft Lumia : 435, 532**

Danh sách CPU h□ tr□ Repair Boot offline:

Qualcomm CPUs :

- **ESM6235**
- **ESM7206A**
- **MSM6000**
- **MSM6150**
- **MSM6245**
- **MSM6246**
- **MSM6250**
- **MSM6250A**
- **MSM6260**
- **MSM6280**
- **MSM6281**
- **MSM6290**
- **MSM6500**
- **MSM6550**
- **MSM6800**
- **MSM6800A**
- **MSM6801A**
- **MSM7200**
- **MSM7200A**
- **MSM7201a**
- **MSM7225**
- **MSM7227**
- **MSM7230**
- **MSM7500**
- **MSM7500A**
- **MSM7501A**
- **MSM7600**
- **MSM7625**
- **MSM7627**
- **MSM8255**
- **MSM8255T**
- **MSM8260**
- **MSM8655**
- **MSM8660**
- **MSM8960**
- **MSM8974**
- **APQ8060**
- **APQ8064**
- **QSC1100**
- **QSC1110**
- **QSC6010**
- **QSC6020**
- **QSC6030**
- **QSC6075**
- **QSC6085**

- **QSC6240**
- **QSC6270**
- **QSD8250**
- **QSD8650**

Texas Instruments CPUs

- **OMAP1710**
- **OMAP2430**
- **OMAP2431**
- **OMAP3430**
- **OMAP3630 (ARM core is Cortex-A8).**
- **OMAP4430 Processor (Cortex-A9 Dual-Core)**.

Marvell CPUs

- **PXA270**
- **PXA271**
- **PXA272**
- **PXA310**
- **PXA312**
- **PXA320**

Samsung CPUs

- **S3C6410**
- **S5PC110**
- **S5PV310 (Exynos 4210)** Processor (**Cortex-A9 Dual-Core**).

Broadcomm CPUs

- **BCM2133**
- **BCM2156B0**
- **BCM21654**
- **BCM5352**
- **ALI3329**

NVIDIA Tegra 2 CPUs

- **AP20H**

Danh sách Samsung h□ tr□ Repair boot (Unbrick Phone) Brick by BOX and Free Tool

- GT-B2710,GT-B2710D,GT-B5510 Galaxy y Pro, GT-B5620 Omnia Pro 5,GT-B7320, GT-B7330, GT-B7510 Galaxy Pro, GT-B7610

- GT-i5500, GT-i5510, GT-i5508, GT-i5700, GT-i5800, GT-i5801, GT-i6410, GT-i8000, GT-i8000L, GT-i8150 Galaxy W, GT-i8160, GT-i8190, GT-i8262, GT-i8320, GT-i8510, GT-i8552, GT-i8700, GT-i8750, GT-i8910, GT-i9000 Galaxy S, GT-i9001 Galaxy S Plus, GT-i9003 Nexus S SL, GT-i9020,GT-i9020T,GT-i9023, GT-i9070, GT-i9100 Galaxy S II, GT-i9100G Galaxy S II, GT-i9103 Galaxy Z, GT-i9105, GT-i9152 Galaxy Meag 5.8, GT-i9158 Galaxy Mega 5.8, GT-I9200, GT-i9205 Galaxy Mega LTE 8GB, GT-i9250, GT-I9295 Galaxy S4 Active, GT-i9300 Galaxy SIII, GT-i9300T, GT-i9500 Galaxy S4, GT-i9500C Galaxy S4, GT-i9505 Galaxy S4 LTE, GT-i9508 Galaxy S4

- GT-M7500, GT-M7600, GT-M8800, GT-M8910

- GT-N7005 Galaxy Note LTE

- GT-S3370, GT-S3650, GT-S3850, GT-S5230, GT-S5230W, GT-S5233S, GT-S5233W, GT-S5250, GT-S5260, GT-S5350,GT-S5360 Galaxy Y, GT-S5380D,GT-S5510, GT-S5520, GT-S5560, GT-S5560C, GT-S5570 Galaxy Mini, GT-S5570i Galaxy Pop, GT-S5600,

GT-S5620, GT-S5660 Galaxy Gio, GT-S5670, GT-S5750, GT-S5830 Galaxy Ace, GT-S5830G,GT-S5830i, GT-S6010,GT-S6012,GT-S6102, GT-S6352,GT-S6500D,GT-S7070, GT-S7220, GT-S7230E, GT-S7250D Wave M, GT-S7330,GT-S7350, GT-S7350i, GT-S7500 Galaxy Ace Plus, GT-S7500L,GT-S7530,GT-S7550, GT-S7562, GT-S7562i,GT-S7572, GT-S8000, GT-S8000H, GT-S8500, GT-S8530, GT-S8600 Wave 3

- GT-P1000 Galaxy Tab, GT-P1000N, GT-P1010, GT-P3100 Galaxy Tab 2,GT-P3113,GT-P6200 Galaxy Tab 7.0 Plus, GT-P6800 Galaxy Tab 7.7

- SC-01C, SC-01G Galaxy Note Edge, SC-02B, SC-03D, SC-04D, SC-05D Galaxy Note, Docomo SC-06D Galaxy SIII, SCL21 Galaxy S3 Progre, SC-01E Galaxy Tab 7.7 Plus, SC-04E Galaxy S4, SC-01F Galaxy Note 3, SC-04F Galaxy S5, SCL22 Galaxy Note 3, SCL23 Galaxy S5, SCL24 Galaxy Note Edge

- SM-A300F Galaxy A3, SM-A500FU Galaxy A3, SM-A300H Galaxy A3, SM-A500F Galaxy A5, SM-A500FU Galaxy A5, SM-A500H Galaxy A5, SM-A500M Galaxy A5, SM-A500G Galaxy A5

- SM-G800H, SM-G850F, SM-G850FD, SM-G850FQ, SM-G850K, SM-G850L, SM-G850S, SM-G850M, SM-G850Y, SM-G850W, SM-G870A, SM-G900A, SM-G900L, SM-G900K, SM-G900S, SM-G900T, SM-G900H, SM-G900P, SM-G901F, SM-G906L, SM-G906S, SM-G906K

- SM-N900A Galaxy S5, SM-N900T, SM-N900J (SCL22), SM-N900D (SC-01F), SM-N900P, SM-N910A Galaxy Note 4, SM-N910C, SM-N910K, SM-L910L, SM-N910H, SM-N910P, SM-N910T, SM-N910S, SM-N910F, SM-N910U, SM-N910V, SM-N910R4, SM-N910W8, SM-N915G Galaxy Note Edge, SM-N915T, SM-N915S, SM-N925F Galaxy S6

- SM-T325, SM-T331

- SCH-i535

- SGH-A767, SGH-A777, SGH-A837, SGH-A867, SGH-A877, SGH-A887, SGH-A897

- SGH-F330, SGH-F480, SGH-F480V, SGH-F490, SGH-F490V

- SGH-G800

- SGH-I337, SGH-i450, SGH-i520, SGH-i547,SGH-i550, SGH-i560, SGH-i600, SGH-i640v, SGH-i710, SGH-i718, SGH-i727,SGH-i728, SGH-i740, SGH-i747, SGH-i747M Galaxy SIII LTE,SGH-i757, SGH-i757M, SGH-i777, SGH-i780, SGH-i827, SGH-i897, SGH-i900, SGH-i908, SGH-i908E, SGH-i910, SGH-i997

- SGH-J200, SGH-J208

- SGH-L810, SGH-L810V, SGH-P960

- SGH-T469, SGH-T479, SGH-T499, SGH-T589, SGH-T599, SGH-T669, SGH-T749, SGH-T759, SGH-T769, SGH-T849, SGH-T919, SGH-T959, SGH-T959P, SGH-T959P, SGH-T989, SGH-T999 Galaxy SIII, SGH-T999V Galaxy SIII.

- SGH-U700, SGH-U700B, SGH-U700V, SGH-U708, SGH-U800, SGH-U900, SGH-U900T, SGH-U908.

- SGH-Z140, SGH-Z230, SGH-Z400, SGH-Z500, SGH-Z540, SGH-Z720, SGH-ZV30, SGH-ZV40, SGH-ZV50, SGH-ZV60.

- SM-N9005

- YP-G70EW Galaxy S WiFi

□ Danh sách Samsung Anycall h□ tr□ Repair Boot (Unbrick Phone) Brick by Vygisbox, SPTBOX, Octopus Box and Other Free Tool..

- SCH-W200, SCH-W210, SCH-W240, SCH-W250, SCH-W270, SCH-W300, SCH-W320, SCH-W330, SCH-W340, SCH-W350, SCH-W360, SCH-W380, SCH-W410, SCH-W420, SCH-W450, SCH-W460, SCH-W550, SCH-W555, SCH-W560, SCH-W570, SCH-W580, SCH-W590, SCH-W600, SCH-W720, SCH-W740, SCH-W750, SCH-W760, SCH-W770, SCH-W780, SCH-W820, SCH-W830, SCH-W850, SCH-W860, SCH-W880, SCH-W890, SCH-W900, SCH-W910, SCH-W920, SCH-W930, SCH-W940, SCH-W960

- SPH-W2400, SPH-W2500, SPH-W2700, SPH-W2900, SPH-W3000, SPH-W3300, SPH-W3400, SPH-W3500, SPH-W3600, SPH-W4100, SPH-W4200, SPH-W4700, SPH-W5000, SPH-W5200, SPH-W5300, SPH-W5310, SPH-W5500, SPH-W5700, SPH-W5900, SPH-W6000, SPH-W6300, SPH-W6310, SPH-W7100, SPH-W7700, SPH-W7900, SPH-W8200, SPH-W8300, SPH-W8400, SPH-W8500, SPH-W8700, SPH-W9000, SPH-W9100, SPH-W9300, SPH-W9500, SPH-W9600

- SHW-A110K, SHW-A110S, SHW-A130K, SHW-A130S, SHW-A160S, SHW-A180S, SHW-A200K, SHW-A200S, SHW-A210S, SHW-A220K, SHW-A220S, SHW-A240S, SHW-A250K, SHW-A250S, SHW-A280S, SHW-A280K, SHW-A300S, SHW-A300K, SHW-A310K, SHW-A310S

- SHW-M110S Galaxy S, SHW-M130K Galaxy K, SHW-M180S Galaxy Tab, SHW-M190S, SHW-M210S, SHW-M220L, SHW-M250K Galaxy S II, SHW-M250S Galaxy S II, SHW-M250L, SHW-M290K Galaxy Gio, SHW-M290S Galaxy Gio, SHW-M420K Galaxy Nexus

- SHV-E110S Galaxy SII LTE, SHV-E120S Galaxy SII HD, SHV-E120K, SHV-E120L, SHV-E160S Galaxy Note, SHV-E160L Galaxy Note, SHV-E160K Galaxy Note LTE, SHV-E210L Galaxy SIII, SHV-E210K Galaxy S3, SHV-E210S Galaxy SIII

- SCH-M480, SPH-M4800, SCH-M620, SPH-M6200, SCH-M710, SCH-M715, SCH-M720, SPH-M7200

Danh sách Samsung Softbank h□ tr□ Repair Boot (Unbrick Phone) Brick by Z3X BOX, SPT BOX, UST BOX

- 707SC, 708SC, 709SC, 730SC, 740SC, 805SC, 820SC, 821SC, 920SC, 930SC, 940SC

Danh sách LG CYON h□ tr□ Repair Boot (Unbrick Phone) Brick by Z3X BOX, VYGISBOX, OCTOPUS BOX and Other Free tool

- LG-KH1200, LG-KH1300, LG-KH1400, LG-KH1600, LG-KH1800, LG-KH1800M, LG-KH2100, LG-KH2200, LG-KH2700, LG-KH3100, LG-KH3400, LG-KH3900, LG-KH4500, LG-KH6400, LG-KH6500, LG-KH8000, LG-KH8200, LG-KH8600

- LG-KU1700, LG-KU2000, LG-KU4000, LG-KU6000, LG-KU6300, LG-KU9000, LG-KU9300, LG-KU9500, LG-KU9600

- LG-SH110, LG-SH130, LG-SH150, LG-SH150A, LG-SH170, LG-SH210, LG-SH240, LG-SH400, LG-SH410, LG-SH460, LG-SH470, LG-SH490, LG-SH640, LG-SH650, LG-SH810, LG-SH860

- LG-SU100, LG-SU200, LG-SU410, LG-SU600, LG-SU630, LG-SU640 Optimus LTE, LG-SU660 Optimus 2x, LG-SU910, LG-SU950, LG-SU960

- LG-LV7400, LG-LV7400R, LG-LU2300, LG-LU6200 Optimus LTE

- LG-F100L Optimus Vu, LG-F100S Optimus Vu, LG-F120L Optimus LTE Tag, LG-F120K Optimus Tag, LG-F120S Optimus Tag, LG-F160L Optimus LTE2, LG-F160S Optimus LTE2, LG-F160K Optimus LTE2, LG-F160LV Optimus VoLTE, LG-F180K Optimus G, LG-F180L Optimus G, LG-F180S Optimus G, LG-F200L Optimus Vu II, LG-F200K Optimus Vu II, LG-F200S Optimus Vu II, LG-F240K Optimus G pro,LG-F240L Optimus G Pro,LG-F240S Optimus G pro,LG-F260S Optimus LTE 3..., LG-F310L, LG-F310LR, LG-F320L Optimus G2, LG-F320K Optimus G2, LG-F320S, Optimus G2, LG-F340L Optimus Flex, LG-F350L, LG-F350K, LG-F350S, LG-F400L, LG-F400K, LG-F400S, LG-F410S, LG-F460L, LG-F460K, LG-F460S, LG-F470L, LG-F470K, LG-F470S, LG-F490L

Danh sách LG h□ tr□ Repair Boot (Unbrick Phone) Brick by BOX and Free Tool

- LG-C660H,LG-C660R,LG-CT810, LG-CU720, LG-C729, LG-C800, LG-CU920

- LG-D800 Optimus G2, LG-D802 Optimus G2, LG-D850, LG-D850A,

- LG-E400, LG-E400G, LG-E405, LG-E610, LG-E610GO, LG-610V, LG-E612, LG-E617G, LG-E720, LG-E900,LG-E906,LG-E970,LG-E971,LG-E973,LG-E975, LG-E975W, LG-E988

- LG-GD880, LG-GM730, LG-GM750, LG-GT540, LG-GW550, LG-GW620

- LG-KC910, LG-KC910i, LG-KS20

- LG-P350, LG-P500, LG-P693,
LG-P700,LG-P705f,LG-P705g,LG-P705GO,LG-P708g,LG-P870,LG-P930,LG-P936, LG-P970, LG-P990, LG-P999

- L-01E, L-01D, L-01F, L21, L22, L23, L24

□ Danh sách Pantech SKY h□ tr□ Repair Boot (Unbrick Phone) - Brick by Vygisbox or other Free tool

- SKY IM-A600S, SKY IM-A630K, SKY IM-A650S, SKY IM-A690S, SKY IM-A740S, SKY IM-A760S Vega Racer, SKY IM-A770K Vega Racer, SKY IM-A800S, SKY IM-A810S, SKY IM-A810K, SKY IM-A820L, SKY IM-A830L Vega Racer 2, SKY IM-A830S Vega racer II, SKY IM-A830K Vega Racer 2, SKY IM-A840S Vega S5, SKY IM-A850K Vega R3, SKY IM-A850L Vega R3, SKY IM-A850S Vega R3, SKY IM-A870K Vega iron, SKY IM-A870L Vega Iron, SKY IM-A870S Vega IRON, SKY IM-T100K Vega No5, SKY EF33S, SKY EF34K, SKY EF39S, SKY EF40S, SKY EF40K, SKY EF44S, SKY EF65L, SKY IM-A880S, SKY IM-A890L, SKY IM-A890S, SKY IM-A890K, SKY IM-A900L, SKY IM-A900S, SKY IM-A900K, SKY IM-A910L, SKY IM-A910S, SKY IM-A910K, SKY IM-A920S

- SKY IM-R300, SKY IM-R470S, SKY IM-R520S

- SKY IM-S240K, SKY IM-S350, SKY IM-S370, SKY IM-S380K, SKY IM-S410, SKY

IM-S410K, SKY IM-S550S, SKY IM-S610K

- SKY IM-U220, SKY IM-U220K, SKY IM-U310, SKY IM-U310K, SKY IM-U440K, SKY IM-U440S, SKY IM-U460K, SKY IM-U490S, SKY IM-U530K, SKY IM-U560K, SKY IM-U570K, SKY IM-U585S, SKY IM-U590S, SKY IM-U660K...

- Pantech P6030, Pantech P8010, Pantech P9070

□ Danh sách HTC Smart phone h□ tr□ Repair Boot (Unbrick Phone)

- HTC Artemis, HTC Athena H3, HTC Chief, HTC Click, HTC Dash, HTC Desire, HTC Desire CDMA, HTC Desire HD, HTC Desire S, HTC Desire Z, HTC Diamond, HTC Dream, HTC DroidEris, HTC Elf, HTC Gene 100, HTC HD, HTC HD2, HTC HD7, HTC Herald, HTC Hero, HTC Imagio, HTC Incredible C, HTC Jade, HTC Legend, HTC Magic 32A, HTC Magic 32B, HTC Magic SAPP400, HTC Mega, HTC Mozart, HTC Nexus, HTC Nike, HTC Polaris, HTC Raphael, HTC Rhodium, HTC Rhodium W, HTC Snap, HTC Supersonic, HTC Tattoo, HTC Topaz, HTC Trophy, HTC WildFire, HTC WildFire S, HTC Wings, HTC Wizard, HTC Sensation,HTC Senstation XL 315e, HTC Senstation XL 315b, HTC Shooter,HTC Pyramid, HTC EVO 3D, HTC Inspire 4G A9192, HTC Stallion, HTC 7 Pro, HTC One V(HTC Prim),HTC Flyer,HTC Rhyme (HTC Bliss),HTC Rada (HTC Omega), HTC 7 Serround (HTC Mondrian), HTC Chacha A810E, HTC One V,HTC Amaze 4G (HTC Ruby)..

□ Danh sách các lo□i đi□n tho□i khác & Modem h□ tr□ Repair Boot(Unbrick)

SONY XPERIA :

- **Sony Xperia Z1 : C6902, C6903, C6906, C6943, L39h, L39t, L39u, SO-01F, SOL23**
- **Sony Xperia Z1s : C6916, C6916 T-mobile**
- **Sony Xperia Z : C6602, C6603, C6616, C6606, SO-02E, L36h**
- **Sony Xperia Z Ultra : C6802, C6806, C6833, C6843, XL39h, SOL24**
- **Sony Xperia ZL : C6502, C6503, C6506, L35h**
- **Sony Xperia ZR : C5502**
- **Sony Xperia SP : C5303**
- **Sony Xperia V : LT25i**
- **Sony Xperia Z4 : SO-03G, SOV31, 402SO**
- **Sony Xperia Z4v : E6508**
- **Sony Xperia Z3+ : E6533, E6553**

Toshiba :

- Toshiba G810, Toshiba G900, Toshiba G910, Toshiba TG01, Docomo T01A, Softbank X02T

Huawei :

- Huawei C2607, C2806M, C2807, C2808, C2809, C2823, C2830, C2901M, C2905, C2906,

C5055, C8500

- Huawei E1750,E17X, E156G,E169, E169G, E585, E1550, EC189, EC1260,EC3061

- Huawei U2801, U7519,U8100-9, U8160, U8180 (IDEOS X1), U8350, U8500, U85101,U8651T,U8652,U8800 Pro

ZTE :

- ZTE C335, ZTE C370, ZTE F285

- ZTE MF102,ZTE MF622, ZTE, MF626, ZTE M627, ZTE M628, ZTE P736V

- ZTE R518, ZTE S100, ZTE S160, ZTE S1602

- ZTE V875, ZTE V889F

HTC :

- **HTC HTL21, HTC J One HTL22,□**

□ Nokia / Microsoft Lumia (Repair boot - Unbrick)

- **Lumia 920 (RM-820, RM-821, RM-867)**
- **Lumia 820 (RM-824, RM-825)**
- **Lumia 620 (RM-846)**
- **Lumia 928 (RM-860)**
- **Lumia 1020 (RM-875, RM-876, RM-877)**
- **Lumia 720 (RM-885, RM-887)**
- **Lumia 925 (RM-892, RM-893, RM-910, RM-955)**
- **Lumia 520 (RM-913, RM-914, RM-915, RM-917)**
- **Lumia 625 (RM-941, RM-942, RM-943)**
- **Lumia 1320 (RM-994, RM-995, RM-996)**
- **Lumia 525 (RM-997, RM-998)**
- **Lumia 1520 (RM-937, RM-938, RM-939, RM-940)**
- **Lumia 635 (RM-974, RM-975, RM-1078 Sprint)**
- **Lumia 630 (RM-976, RM-977, RM-978, RM-979)**
- **Lumia 638 (RM-1010)**
- **Lumia 530 (RM-1017, RM-1018, RM-1019, RM-1020)**
- **Lumia 638 (RM-1027)**
- **Lumia 830 (RM-983, RM-984, RM-985, RM-1049)**
- **Lumia 735 (RM-1038, RM-1039, RM-1040)**
- **Lumia 929 (RM-927)**
- **Lumia 930 (RM-1087)**
- **Lumia 710**
- **Lumia 800**
- **Microsoft Lumia : 435 (RM-1068, RM-1069, RM-1070, RM-1071)**

- **Microsoft Lumia : 532 (RM-1031, RM-1032, RM-1034)**
- **Microsoft Lumia : 535 (RM-1089, RM-1090, RM-1091, RM-1092)**

Other :

- **TAKE KM-S200, KM-S220, KM-S330,EV-S100, SK-S100, Ktech KM-E100 Take LTE**

PS : Vui lòng sao chép ghi rõ ngu□n g□c



Trung Tâm Giải Mã Điện Thoại Vũ Ngọc - Mobile. HOTLINE: 0979.913.808
Địa chỉ: Số 04 đường Thiên Đức - Phường Vệ An - TP Bắc Ninh (Cách Bến Xe TP 20